



C7 HATCH/TRUNK LED STRIP KIT




Remove either rear hatch light housing by prying it out at the inner edge. (red arrow).



Pull up on the weather strip so you can route LED wires behind the panel and through the light opening. (red arrow).



Strip back the wire covering so you can install the supplied connectors. Make sure the connectors are at least 2 inches away from housing to allow re-installation of the housing. Place each wire into the metal clip and fold the clip closed until it clicks shut. You may have to use a pair of pliers.



Now plug the led strip leads into the back of the connectors as shown. Red connects to the green wire and black to black. LEDs should now light up. If not, make sure the interior lights have not timed out which they will do after about 15 minutes. Open and close the door or start the car to reset.



Center the led strip just below the weather strip. Clean the mounting area with supplied alcohol prep pad and let dry. Cut the top off the adhesion promoter packet and wring out the excess fluid back into the packet. Seal the packet as best you can to preserve the rest of the fluid so you can use it to install other kits you may have purchased. Spread a thin layer on the area where you are mounting the led strip. Let dry. Peel adhesive backing off and stick led strip in place. Press strip in place for a few minutes to promote adhesion.



Hide wires under weather strip, replace light housing and enjoy the new lighting!