
PLEASE - READ ME FIRST
Installation instructions
for the PANA VEX mirror

Thank you for purchasing the PANA VEX mirror for your vehicle. Since 1985, PANA VEX Products has been providing this simple and economical accessory for discriminating drivers. After just a few days, many have wondered how they ever got along without it!

Installation takes just a few minutes, however to ensure a proper fit and adhesion, please read through this sheet before attempting to install the mirror on your vehicle. **NOTE: The pressure sensitive tape bonds instantly on contact - offering NO opportunity for a second attempt or removal without possible damage to the factory or PANA VEX mirrors.**

On some vehicles, PANA VEX mirrors are made for left and right applications. They are *not* interchangeable due to the convex radius. Confirm you have received the correct version for your application. **IF YOU HAVE ANY QUESTIONS CONTACT US OR YOUR SUPPLIER BEFORE CONTINUING THE INSTALLATION OF THE PANA VEX MIRROR.**

Step 1:
Check size & shape



Apply the supplied suction cup to the front of the PANA VEX mirror for ease of handling and installation. **DO NOT REMOVE THE GREEN PROTECTIVE STRIP AT THIS TIME.** Check the size and shape against the original factory mirror. The PANA VEX mirror should cover the original mirror completely and closely conform to it's shape.

Step 2:
Clean the factory mirror



Clean the factory mirror with a conventional glass cleaner, removing all residual grease, tar, and dirt. Any residue might result in a less than perfect bond between the PANA VEX and factory mirrors. This is good time to try a few "Dry" runs of applying the PANA VEX mirror. In step 3 you will only get one opportunity to get it right!

Step 3
Remove strip - apply mirror



Remove the green protective strip from the back of the PANA VEX mirror, and carefully apply it to the factory mirror. Avoid touching the adhesive tape. **DO NOT EXERT EXCESSIVE PRESSURE TO THE CENTER OF THE PANA VEX MIRROR AS THIS WILL CAUSE IT TO BREAK.** *It is normal for a small gap to exist between the center of the PANA VEX mirror and the factory mirror.*

Step 4
Apply pressure to edges



Apply a small amount of pressure at the extreme right and left edges of the PANA VEX mirror. **Do not apply pressure to center,** the small gap provides for expansion and contraction between the two mirrors. The adhesive tape bonds instantly, however it will become stronger over the next days. You are ready to go!