

AMERICAN CAR CRAFT

C6 Z06 CORVETTE STOCK AIR TUBE COVER

INSTALLATION INSTRUCTIONS

Items Included:

Air Tube Cover

1-Pack of Adhesive Promoter

4-Self Tapping Screws

4-White Sockets

2- Small Chrome Cap Covers

2-Large Chrome Cap Covers

Your new cover comes to you with a protective liner. Do not remove liner until prompted by the instructions.

1. Your new two piece cover comes to you pre-shaped however it will be necessary to further shape and form each piece by hand in order to achieve a nice snug contoured fit.
2. Thoroughly clean the entire air tube with household isopropyl alcohol to remove any dirt and grime. Then swipe the area once with the adhesive promoter provided.
3. Remove the top of the air tube stud retainer NOT THE ENTIRE STUD. This will expose a small hole at the top of each stud.
4. Peel the red release liner from the back of the larger cover and carefully place it onto the factory air tube. Press firmly at all points to set.
5. You will notice a small hole on each side of the cover towards the front of the car. Fasten the new cover using the two self tapping screws provided thru the two white sockets. Be careful not to over tighten! Remove the protective liner and snap on the two small chrome cap covers. Repeat this screw assembly for the top two holes and fasten to the stud hole exposed earlier. Snap the two large chrome caps onto the white sockets.

6. Peel the red release liner from the back of the small section and firmly press into position onto the factory air tube to set. Remove protective liner.

Thank you and enjoy your new purchase.

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.