

# **AMERICAN CAR CRAFT**

## **CORVETTE STAINLESS STEEL BRAKE PAD COVERS**

### **INSTALLATION INSTRUCTIONS**

- 1. Jack up your Corvette and remove wheel.**
- 2. Loosen both caliper retaining bolts but do not remove.**
- 3. Remove top bolt only.**
- 4. Rotate caliper just enough to expose the front of your factory brake pad.**
- 5. Apply a small smear of household silicone to the back of your new stainless pad plate and place it over the brake pad.**
- 6. Reposition brake caliper and tighten SECURELY!**
- 7. Follow steps 1-6 for your 3 remaining wheels.**

**PLEASE NOTE:** These custom pad covers in NO way alter your braking system. American Car Craft and its distributors will not be responsible for any improper installations; such as loose bolts or improper placement that may cause any danger or damage in any way, shape or form. Please follow instructions carefully and be sure to put your brakes back together safely and securely!