

AMERICAN CAR CRAFT

C6 CORVETTE STAINLESS STEEL RETRO GRILLE

INSTALLATION INSTRUCTIONS

Your new retro grille comes to you preformed however it will be necessary to force the grille into and onto the factory grilles horizontal rib.

1. Carefully and accurately tape your grille opening completely top, bottom and sides using a 2" to 3" masking tape. This step is done in order to protect your paint during installation.
2. You have been provided with 4 long zip ties. Slide these zip ties in the space between the teeth and the horizontal bar at the four locations indicated by the dot. Using a small piece of masking tape, tape the zip tie to both the top and bottom of the horizontal bar forming a "U" shape. This will allow you to place the grille into position leaving the zip ties exposed behind the factory grille.
3. Carefully place the grille into position. Using both hands grip the grille and squeeze the center bar onto and into the factory grille horizontal bar. You will find that it will take the shape of the grille and pretty much stay in position.
4. Lay with your back to the floor reach thru the front grille with your fingers of one hand as you reach under the car and around the back of the grille with your other hand align the two ends of the zip tie attach them and pull to fasten securely. Apply this step to all four zip ties. Adjust the grilles position so that it sits evenly and securely in the factory opening.
5. Remove the protective masking tape.

Note: Care must be taken when cleaning your grille. It is a good idea to lightly dust your grille with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe using a new clean soft cloth with a good quality streak free glass cleaner.

Thank you and enjoy your new purchase!

