

Installation Instructions for Panoramic Door Mirror

**Please read this important Disclaimer
Notice:**

By installing, attempting to install, or by using our product in any manner you are demonstrating that you clearly understand and agree with the terms of our Limited Liability Policy. Our Limited Liability Policy can be found on our website here:

<https://www.sandyeggodesigns.com/liability-disclaimer-notice>.

Revised: 01/27/2023

Tools: None

Skill Level: Easy; Please read all instructions before starting.

Test First

We highly recommend you test your new mirror before installing it. You can test it by (1) simply having it held in place by hand while sitting in your car, or (2) temporally attaching it using any household tape to preview the mirror. If you are satisfied with the quality and view of the mirror, proceed to the installation below.

Prepare the mounting surface

1. The working temperature should be between 70 and 90 degrees Fahrenheit.
2. Clean the door mirror glass using soap and water. Rinse thoroughly and let dry.
3. Use rubbing alcohol wipe to de-grease the glass surface. Let the glass and frame dry completely.

Prepare the Panoramic Mirror

1. Remove backing from all mounting tape.

Mount the Panoramic Mirror

1. Visually align the Panoramic Mirror to the door mirror glass.
2. Lightly press the Panoramic Mirror against glass. **It is very difficult to remove the Panoramic Mirror once set so MAKE SURE OF ALIGNMENT before pressing against glass!**

Secure the Panoramic Mirror

1. Apply firm, even pressure over the Panoramic Mirror surface for 30 seconds to ensure it is securely attached to the door mirror glass.

Let set

1. Wait at least one hour before exposing the Panoramic Mirror to moisture or vibration. After 72 hours, the bond becomes almost indestructible. The 3M™ VHB™ tape has extremely high adhesion and will resist most solvents and temperatures up to 300 degrees Fahrenheit.

Test

- Take sufficient time to get used to the reflection provided by the Panoramic Mirror.
- Due to its complex shape there will be some image and spatial distortion.
- **Remember that objects in the Panoramic Mirror are closer than they appear.**

Mirror Removal

In the event you want to remove a Panoramic Mirror, these steps may be helpful. Other advice is available by doing an Internet search for "3M VHB tape removal" or "how to remove vhb tape".

1. **Avoid using any metal or hard tool that may scratch the original glass.**
2. Using a hair dryer, heat the glass until its hot to the touch.
3. Spray WD-40 liberally into the gap between the back of the Panoramic Mirror and the original car mirror. Let soak for several minutes.
4. Use a thin strong thread, fishing line, or dental floss to saw back and forth against the tape.
5. Apply more heat and WD-40 as needed.
6. Once the tape is sawn through, any adhesive residue can be cleaned off the original glass using acetone or 3M™ Adhesive Remover.
7. Once you have got most of the tape off, use soapy water to clean off any traces of both the tape and WD-40 and then use a towel to wipe the surface dry.