

AMERICAN CAR CRAFT

C6 2-pc STAINLESS PERFORATED VENT GRILLES

INSTALLATION INSTRUCTIONS

PARTS INCLUDED:

2-Stainless Perforated Vent Grille w/attachment tape

2-Adhesive Promoter Packs

2-12" Strips of Installation Molding

- 1. Jack up the front of your car and support the vehicle with a pair of jack stands to ensure safety.**
- 2. Turn the wheel sharply to create adequate working clearance and remove the retainers that secure the plastic inner fender to the painted outer fender. Doing this creates access to the inner side of the fender vent hole. Once you have created this access you will need to reach in and separate the vent opening deflector from the outer fender do this by detaching it with your hand. This will create full access to the vent hole.**
- 3. Using a cloth with soap and water wipe the inner side of the vent on both sides of the hole to remove road grime and dirt. Once this area is clean scrub both sides of the vent hole with household isopropyl alcohol until thoroughly clean.**
- 4. You have been provided with two packets of adhesive promoter. Use one of them and swipe the inner and outer sections of the inside of the vent hole.**
- 5. Place the vent grill into position behind the vent hole and check the fit. It may be necessary to adjust the vent grille by hand in order to achieve a nice perfect fit. Adjustments can be made if necessary by forcing the shape of the curve against the floor or hard surface (or the angle of the bend could be adjusted with a pair of pliers).**
- 6. Once the grille has been fitted you may begin permanent installation. Peel the red liner from the attachment tape and firmly set into position being sure to firmly press both the vent grille on the inside and the vent opening on the outside fender simultaneously in order to achieve a full permanent bond.**

7. **You have been provided with two molding strips. Use one of them to secure the back side of the outer edge of the grille by removing the release liner completely from the molding strip and then setting it firmly in place locking the grille to the outer fender. Be sure to again press firmly on the molding from both the inside of the vent hole and the outside of the fender simultaneously in order to set a permanent bond. Then be sure to push your vent deflector back into place. Then replace the inner fender retainers.**
8. **Repeat steps 1-7 for opposite side.**

Thank you and enjoy your purchase!

