

AMERICAN CAR CRAFT

18924 SAKERA RD HUDSON FL 34667

Phone: 727 861-1500 Fax: 727 861-1520

www.americancarcraft.com

C6 CORVETTE SIDE MARKER LIGHT BEZELS

PART# C609-3 #C609-3Z patent pending

INSTALLATION INSTRUCTIONS

PARTS INCLUDED:

4-Stainless Side Marker Bezels

2-Adhesive Promoter Tubes

Your side marker bezels are designed to go around your side marker lights and attach directly to the painted surface.

1. Clean the area around each of the side marker lights with household rubbing alcohol to remove any wax and dirt then swipe the area once with the adhesive promoter tube provided.
2. Place each bezel into position to familiarize yourself with each placement before removing the liner. It WILL BE necessary to HAND FORM the bezels to CONFORM to the shape of the car doing this will prevent any possibility of the bezel popping loose or lifting long term.
3. Once they are fitted properly peel the release liner from the back of each bezel and carefully set them nice and evenly around each light. Press firmly to set.

DO NOT GET WET FOR 24 HOURS.

IF ANY QUESTIONS OCCUR DURING INSTALLATION PLEASE CONTACT AMERICAN CAR CRAFT AT 727-861-1500.

Thank You and Enjoy Your New Purchase.