

AMERICAN CAR CRAFT

C6 Z06 CORVETTE RADIATOR COVER

INSTALLATION INSTRUCTIONS

Items Included:

___1-Stainless Radiator Cover

Your new cover comes to you with a protective liner. Do not remove liner until installation is complete.

1. Loosen the large air tube clamp securing it to the engine and detach the tube at this location but do not remove.
2. You will notice two rubber grommets securing the air tube to the factory radiator cover via two plastic studs. These studs are a two part retainer removable by pulling the round top plunger from its base which will allow you to pull the stud assembly out completely.
3. Carefully position the new cover by placing it over the factory air tube as you slide it under the two air tube ears and line up the holes in the new cover with the holes on the factory radiator cover that you just exposed. At this time you will check the shape and overall fit of the new cover. Although the new cover comes to you pre-shaped it may be necessary to adjust the fit by hand so that the new cover sits nicely under the front nose section and flat to the factory cover.
4. With the cover nicely fitted in position reinstall the two factory air tube retainer studs by placing them directly thru the new cover into the factory cover and forcibly resetting the center plunger to lock the new cover in place. Then simply reattach the factory air tube.
5. Remove the protective liner.

Thank you and enjoy your new purchase.

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak

free glass cleaner.

