

1978-1982 Corvette Outer T-Top Molding Kit

Product # HT-425

Installation Instructions

Step 1. Remove tops from car and place on table or workbench covered by a soft cover to protect the glass.

Step 2. Remove old trim from tops. Pull off or cut with razor blade if needed.*

*Note: Do not use the razor blade edge directly on the underneath tint on the M-92A or M94-A glass as it will scratch the interior coating.

Step 3. Clean tops in trim area with any cleaner that does not contain oil.

Step 4. Cut small hole in glue cap and apply inside new trim.

Step 5. Place new trim on tops using pressure to make contact with glass. Use a small roller if available to apply pressure for better contact. Begin installation of trim at rear of t-top panel connecting outside rear and inside rear corners. Continue installation up the inside edge from inside rear corner to inside front corner, then install glass trim from front corner around leading edge of top panel to the rear outer corner.

Step 6. Secure in place with masking tape in several areas to hold trim flat against glass during drying period.

Step 7. Allow 12 hours to cure. Once dried, remove any excess glue with razor blade being careful not to cut into new trim.

Step 8. Clean tops and install on Corvette.

**www.zip-corvette.com
1-800-962-9632**



Zip: Corvettes are all we do.