

AMERICAN CAR CRAFT

C5 FENDER COVER EXTENSION

INSTALLATION INSTRUCTIONS

- 1. Pull up the cowl gasket at the drivers' side.**
- 2. Clean area.**
- 3. Apply 2 or 3 spots of clear household silicone on the cowl where your new fender extension is to be installed. Set in place and replace gasket.**
- 4. Allow 24 hours to dry.**

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.