

AMERICAN CAR CRAFT

C5 or C6 CORVETTE 2-pc FUEL RAIL COVERS

INSTALLATION INSTRUCTIONS

Your new covers come to you with a protective liner. Do not remove liner until installation is complete.

- 1. Your new fuel rail covers have been designed to snap over the existing factory covers. Simply remove the stock fuel rail covers and snap the new covers over top of them. Using a small rubber mallet tap the two small tabs over to lock in position and reinstall your covers.**
- 2. Once you have successfully reinstalled your covers remove the protective liner.**
- 3. You have been supplied with a small stainless cap to be placed over the fuel line hood via a BUTAL attachment putty. Simply form and press in place.**

Thank you and enjoy your new purchase.

Note: Care must be taken when cleaning your covers. It is a good idea to lightly dust your covers with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.