

AMERICAN CAR CRAFT

CORVETTE C-5 ALTERNATOR COVER

INSTALLATION INSTRUCTIONS

Items Needed:
9/64 Drill Bit

Parts Included:
2-Screws
2-Plastic Washers
2-Chrome Caps
Stainless Alternator

- 1. Place your new cover into position.**
- 2. Align the two holes in the cover with the main alternator bracket ridge. (This is a small area and must be matched up properly.)**
- 3. Mark holes in cover to ridge in bracket using a fine point marker or scribe.**
- 4. Using a 9/64 drill bit, drill marked holes only about 1/4" deep.**
- 5. Place cover back over drilled areas and place screws (provided) through plastic washers then tighten. BE CAREFUL NOT TO OVER TIGHTEN. Push chrome caps (provided) onto screws until they snap into place.**

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.