

AMERICAN CAR CRAFT

CORVETTE C-5 RADIATOR COVER

INSTALLATION INSTRUCTIONS

- 1. Remove the factory air cleaner assembly sensor harness and lower air tube.**

- 2. Place your new cover over the radiator and check the fit. (It may be necessary to form the cover by hand until it fits flush without forcing it to lay flat to the factory cover.) NOTE: It will be necessary to slightly push down the aluminum A/C fill line to achieve adequate clearance.**

- 3. Reinstall the factory air cleaner at all points and that is it you are done!**

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.