TOOLS AND ADDITIONAL ITEMS REQUIRED

1) Hobby knife or X-acto knife
2) Rubbing alcohol
3) Dry cloth

Before you begin, separate the left and right product sections (identification on the back), and match them to the door handle and lock section of your Corvette. If you wish to make any modifications to the size, length or height of the product (not recommended), now is the time to do so.

Caution: You may notice that the face section of your Corvette's lock and door handle section are 2.5 cm in height. The C-4 Door Handle Renew/ Restore product is approximately 3 cm in height. The extra length is designed to fold under the bottom of lock and handle sections.







STEP 1: Surface Preparation

In order for the product to adhere correctly to the door handle surface, it must be free of all wax, grease, oil or cleaner. The surface area should be smooth and free of rough surfaces or paint chip edges.

1) Use rubbing alcohol ONLY, to clean the surface of the door handle and lock surfaces.

2) If your door handles and lock section have uneven surfaces, due to stone chips or surface damage, use the 600 ultra fine sandpaper (supplied) to smooth out the door handle and lock section surface. When finished wipe off any excess material with a dry cloth.

3) Use the rubbing alcohol ONLY to completely clean the door handle and lock section surface and let dry. Make sure surface is clear of all dirt or debris.

4) KIT #2 ONLY (DHRLP product) : shake the bottle of special formulated liquid polymer. Insert the paper guard between the top door handle & lock section and the corvette body of the handle area. This will prevent getting the product on the paint of your car. Using the fine brush supplied, apply the product on the top and side section in between the handle and door. DO NOT APPLY THE PRODUCT TO THE FRONT FACE OF THE HANDLE OR LOCK SECTION! Let the product dry for 1 hour. If any product is applied to the face it will need to be sanded flat or it will cause an imperfection once the face sections are applied. Note: (DHRLP product is not included in kit # 1)

Corvette Central .com
800-345-4122

DATE	REVISION	AUTH	DR
2/15/2006			

INSTALLATION INSTRUCTIONS

PART NO. 284117 SHEET 1 OF 2

STEP 2: Product Application

Make sure surface is clear of all dirt or debris.

1) Group left and right door handle and lock sections. Each section is identified by a Left or Right label on the back of the product.

2) Start with the left door handle and lock section of car first. At this point apply the left lock section first. The c4dhr product has a special application/ protection film applied on top of the product. Fold down the application film 90 degrees, about 1mm along the top exposing the black of the product. This is necessary so that you can line up the C4DHR with the top left and right sections of the door handle.

3) On a 35-degree angle from the lock section line up the top left and right edge of the product with the top left and right sections of the lock section and apply working downwards. You will also notice that the product is designed to about ½ inch under the lock and handle section. Caution, once product is applied, it cannot be removed or it will lose it adhesive properties. Once applied, slowly peel off the white protection film.

4) Apply the door handle section using the same procedure. Line up the left, middle and right section of the product with the door handle section and apply, working downwards.

5) Wipe the applied product with a dry cloth.

6) Let the product set for 24 hours before attempting to clean or wash.

Installation Of C-4 Lower Door Handle Scratch Guard

This product is designed to prevent paint scratches to the lower section below the door handle.

1) Use a mild wax cleaner to remove wax, oil or dirt from your cars paint (under door handle). Do not use alcohol it may remove the paint!

2) Use two pieces of masking tape (one on front and one on back) to remove the clear product from its backing.

3) Holding only the corners of the product, position it inside the lower door handle section and apply.

4) Rub lightly a dry cloth over the product.

5) Wait 24 hours for the product to dry before washing.