

# **AMERICAN CAR CRAFT**

## **POWER STEERING THROTTLE BODY COVER INSTALLATION INSTRUCTIONS**

- 1. Remove the power steering cap.**
- 2. Remove the 10-mm bolt directly atop the throttle body.**
- 3. Place your new cover over the power steering reservoir and replace power steering cap.**
- 4. Replace the 10-mm bolt through the hole in the bracket under the new cover and tighten.**

**Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.**