

# AMERICAN CAR CRAFT

## C5 Corvette Door Jam Plates

### Installation Instructions

#### ITEMS NEEDED:

Household Isopropyl Alcohol

#### PARTS INCLUDED:

Adhesive Promoter

4-Chrome Flat Caps

**PLEASE NOTE THAT THIS IS A PERMANENT INSTALLATION AND THE NEW DOOR JAM PLATES CANNOT BE REMOVED WITHOUT DAMAGING THEM.**

Your new door jam plates come to you with a protective liner that you will remove after installation. This will help produce a nice clean install.

1. Thoroughly clean the surface area first with soap and water then with household isopropyl alcohol.
2. Then swipe the same area with the adhesive promoter (provided). This promoter will guarantee a good permanent bond.
3. Gently pre-bend the plates to fit. **VERY IMPORTANT: The metal is flexible enough to allow you to gently curve it so that the plates fit the door area without forcing it to lay flat. It should hug the door jam as if it was installed before removing the red liner.**
4. When you are satisfied with the fit, then remove the red liner from the attachment tape and firmly press.

**IT IS VERY IMPORTANT THAT YOU SLOWLY INSERT THE PLATES INTO PLACE, THE ATTACHMENT TAPE IS VERY RELIABLE AND IT MIGHT BE A GOOD IDEA TO MAKE A COUPLE OF TEST FITS BEFORE PULLING THE RED LINER!**

**YOU HAVE ONLY ONE SHOT AT THIS SO GO SLOWLY!**

5. Once in place pull the protective liner off the door jam plates. **You have been provided with 4-chrome flat caps, place a tiny dab of clear silicone to the backs of these caps and place over screw heads for a nice finished look or if you prefer your kit contains a small bit of butyl putting that you can use to install these caps.**