

AMERICAN CAR CRAFT

C5 HOOD CENTER BRACE COVER

INSTALLATION INSTRUCTIONS

DO NOT REMOVE PROTECTIVE LINER UNTIL STEP 4

- 1. Clean entire area with soap and water. Then scrub area with household isopropyl alcohol. Next wipe the entire hood brace area with the adhesive promoter (provided).**
- 2. Before you permanently install your new cover it will be necessary to pre shape the cover so that it conforms to the odd shaped center brace without forcing. It may take a few times to get the fit just right a friend would be very helpful to support it as you gently curve the cover to fit.**
- 3. Once you are satisfied with its shape and overall fit mark a center mark on the hood and on the new cover. This will be your starting point when you are ready to permanently attach.**
- 4. Completely remove the red liner from the attachment tape on the back of this cover. Carefully place the new cover at the center mark making sure that your cover is straight side-to-side. Firmly press your new cover in place starting at the center working out to either side. With a soft clean cloth firmly press entire cover to set. Once completely set remove the protective liner.**

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.