AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com

C5 8pc STAINLESS EMBLEM INSERTS
PART #C528 patent pending

INSTALLATION INSTRUCTIONS

Items Included:
8-Stainless Inserts

1. Clean emblem area first with soap and water to remove any dirt then with household isopropyl alcohol to remove any and all waxes. Let dry.

2. Place each insert into position and make note of its position.

3. Peel red liner and reposition in place. Press firmly to set.

If any questions occur during installation please contact American Car Craft @ 727 861-1500.

Thank you and enjoy your purchase!

Note: Care must be taken when cleaning your inserts. It is a good idea to lightly dust your inserts with a clean soft cloth first in order to prevent any particles from scratching them. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.