



PRODUCT INSTALLATION INSTRUCTIONS FOR THE C6 GROUND EFFECTS KIT

If you require assistance beyond the scope of these instructions, please call technical assistance at : 951-894-7883 or go on-line at: www.rksport.com.

FRONT FACIA

1. **** IMPORTANT ****: Pre-fit all parts prior to prepping & painting to ensure proper alignment and fit to your vehicle.
2. **** NOTE ****: At least two people will be required to perform the install.
3. Clean surface areas of the car where all parts will be applied of all polishes & waxes with a Prepsol, Alcohol or other paint prep cleaner. Cleaning of the surface for 3M/Double-sided tape adhesion is extremely important.
4. Work from one side to the other, left to right, pulling the Red backing from the Double-sided tape as you go around. **** NOTE ****: DO NOT TAKE ALL OF THE BACKING OFF AT ONE TIME.
5. Using the self-tapping screws, secure the Front Facia in the wheel well.

SIDE SKIRTS

1. From the front, begin to remove the backing from the double-sided 3M tape and work your way back doing a little at a time. **** NOTE ****: DO NOT TAKE ALL OF THE BACKING OFF AT ONE TIME.
2. Using the self-tapping screws, secure the Side Skirts in the wheel well.

REAR CANARDS

1. Pull backing of the double-sided tape starting from one side and work your around.
2. **** NOTE ****: DO NOT TAKE ALL OF THE BACKING OFF AT ONE TIME.
3. Using the self-tapping screws, secure the Rear Canards in the wheel well.

PAINTING INSTRUCTIONS

1. **** IMPORTANT ****: All surfaces that are to be painted must be sanded with 150 Grit sand paper as the primer requires a rough surface for adhesion.
2. Clean all surfaces with a wax and grease remover.
3. Prime with urethane primer and with a flex additive.
4. Putty to eliminate any noticeable "pinholes".
5. Re-prime the surfaces if necessary.
6. Pre-fit all parts to vehicle.
7. Hand sand with 320 Grit sand paper.
8. Clean with a wax and grease remover.
9. Paint – ensuring a flex additive is added to the paint.