



**AMERICAN CAR CRAFT INSTRUCTIONS**  
**C6 CORVETTE STAINLESS POLISHED FLAME TAILLIGHT COVERS**

**PART# 042070** patent pending



**PARTS INCLUDED:**

**4-Stainless Taillight Covers**

**2-Tubes of Adhesive Promoter**

**!!!!VERY IMPORTANT!!!!**

**PLEASE READ ENTIRE INSTRUCTIONS BEFORE BEGINNING THIS INSTALLATION**

YOUR NEW COVERS COME TO YOU WITH A PROTECTIVE LINER. DO NOT REMOVE THIS LINER UNTIL INSTALLATION IS COMPLETE!

**These newly designed C6 taillight grills have been designed to install directly to the C6 taillight allowing you access to the light bulb in the event of replacement.**

1 .Thoroughly scrub clean the perimeter of all four taillights. This is a critical step to insure a good long term bond. Once this is done swipe the perimeter with the adhesive promoter tube supplied with your kit.

**2. (DO NOT SCRATCH YOUR PAINT!! you may elect to put some masking tape on your painted surface area) set each taillight cover in place and check the overall shape.** Your new grills come to you preformed to match your taillights however it will be necessary to further shape each grill by hand in order to achieve the best contoured fitment. Once you have shaped the grills simply peel the red release liner from the back of the grill and then carefully set them in place pressing firmly along the outer perimeter to set the bond. Go over the perimeter several times with high pressure and allow 24hrs to complete the bond.

**3. Remove the protective liner.**

**IMPORTANT TECH NOTE: Be sure to allow the top of the new grills to set behind the lens attachment screw in order to allow removal of the lens.**

**AMERICAN CAR CRAFT**  
**18924 SAKERA RD HUDSON FL 34667**  
**Phone: 727 861-1500      Fax: 727 861-1520**  
**[www.americancarcraft.com](http://www.americancarcraft.com)**