



AMERICAN CAR CRAFT INSTRUCTIONS

2014 C7 Corvette Stingray - Side Skirts 22 Gauge Stainless Steel with Carbon/Fiber Glass Overlay

Part# 052067



VIDEO INSTALLATION INSTRUCTIONS

Please Visit: www.youtube.com/watch?v=L3CBWvfotWA

Liner info: Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation. This liner is required to remain on the part until you are instructed to remove it.

PARTS INCLUDED:

- 2-Stainless Steel with Carbon/Fiberglass Side Skirts
- 2-Adhesive Promoters

The all new C7 corvette side skirt has been designed to install utilizing factory screws and requires no drilling or modifications to the body. A very clean sleek looking accessory that is very easy to install and is hand made using high polished 304 stainless laminated with real carbon/fiberglass for a truly high quality accessory worthy of the new Corvette Stingray!



AMERICAN CAR CRAFT INSTRUCTIONS

1. Thoroughly scrub clean the bottom of the cars rocker with alcohol to remove and all road grime and dirt. Then swipe the area with the adhesive promoter provided. This chemical is not a cleaner but an adhesive accelerator and must be used as such in order to insure a good long lasting and permanent bond!
2. Remove all the screws securing the bottom of the rocker panel with the exception of the two slightly recessed screws at the front end of the rocker.
3. Using the help of a friend bring the side skirt into position so that you can get a good idea of how the skirt is intended to fit. Remove the protective liner completely and then peel back the red release liner at the two ends back and towards you just a couple of inches creating a sort of pull tab. Do not remove the liner completely.
4. Set the skirt up to the rocker and install all the screws removed earlier. Set these screws in by hand but do not tighten them just yet.
5. Once all the screws are in place bring the skirt up the rocket to set its position. The holes in the skirt are slightly oblong and will allow you to set the skirt so that the corner of the skirt does not protrude. Once you have a good position pull the red release liner from the attachment tape as you press the skirt to the rocker riding up over the screws. Press the skirt firmly to the rocker to set the bond. Then snug all the screws to finish the installation.

If any questions or problems occur during installation, please contact American Car Craft at 727-861-1500.

Thank You and Enjoy Your Purchase!

AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520
www.americancarcraft.com