



## **DIRECTIONS FOR LENS REMOVAL AND REPLACEMENT FOR RIMLESS FRAMES**

Here is the information on removal and replacement of the C6, C7, , C7, and C7/Z06 logo series sunglasses that come with a set of copper driving lenses. Just be sure to take your time and if it does not fit, you have not got the tab in the correct part of the frame. Thank you!

1. With the frame facing you, hold the top upper middle part of the right side frame in your left hand and grasp the frame between your thumb and forefinger (right hand with forefinger on upper part of frame just forward of the temple. Now pull up slightly. The lens will come away from the frame. Now grasp the lens and pull it from the frame making certain not to pressure the frame too much). Now repeat the procedure with the opposite lens while holding the sunglass frame in your opposite hand.

As you can see, the frame has a groove in it where the tabs on the upper lens fit into the upper outer corners of the frame. To replace the lens, pull out slightly on the frame and put more pressure on the lens than the frame to make certain that it fits in the upper groove of the frame. Place the outer part of the lens in frame first and open up the frame just enough to allow you to follow the upper groove of the frame and place the tabs back into it.

~ 3569 Somerset Circle Kissimmee, FL 34746 ~  
~ Phone ~ (847) 502-0088 ~ Fax (847) 719-1188 ~  
~ Visit our web site at [www.corvetteeyewear.com](http://www.corvetteeyewear.com) ~  
~ E-mail us at [corvetteeyewear@aol.com](mailto:corvetteeyewear@aol.com) ~