



AMERICAN CAR CRAFT INSTRUCTION

CORVETTE 5TH BRAKE LIGHT CROSS FLAG

PART#042115

PARTS INCLUDED:

- ___ 1-Stainless Brake Light Bezel
- ___ 1-Adhesive Promoter Tube

1. Thoroughly clean the surface of the factory brake light lens with alcohol to remove any and all dirt and wax. Test the surface by applying a strip of masking tape to see if the surface has been cleaned enough to achieve a tack. If the masking tape sticks then swipe the lens with the adhesive promoter provided. **WARNING** some factory lenses have been found to react to the adhesive promoter and may leave an ashy finish. In order to avoid this try to apply the adhesive promoter only to the thin area to be mounted with the bezel and not to the main body of the lens. Or if you can be very certain that you have removed the entire surface contaminates you can then mount the new light bezel without using the adhesive promoter if you prefer. Before you permanently attach the bezel it is important to shape the new bezel by hand so that it exactly matches the shape of the factory lens without having to force the bezel to set flat. **NOTE:** If you consider that metal will **NOT** bend itself out of shape than you can expect that if you install a nicely shaped bezel conformed to the factory lens that it will remain in place and not lift off the factory lens over time or being exposed to the elements.

2. Now that you have a nicely shaped bezel simply remove the release liner from the back of the new bezel and carefully set the bezel in position. Press the bezel firmly along its entire length to set. Do not get wet for 24 hours.

If any questions occur during installation please contact American Car Craft @ 727 861-1500.

Thank you and enjoy your purchase!

Note: Care must be taken when cleaning your bezel. It is a good idea to lightly dust your bezel with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.