

Suggested Installation Instructions for Product Number:
612-743
1984-1996 Blackout Headliner Roof Panel

CAUTION C3/C4 Corvettes: The soft, black rubber seal that surrounds the top frame is very fragile. The headliner blackout's mounting tabs are designed to slide under this seal, directly against the glass carefully so no damage is done to the seal.

To Install:

1. Clean top's glass.

Hint: Remove the top from the vehicle and place on soft cloth to mount the headliner blackout.

2. To slide the mounting tabs between the glass and the black rubber seal, "bow" the headliner blackout (front to back first, then pop in the sides).
3. Headliner blackout simply "pops" into place. Adjust the headliner blackout from left to right, front to back as necessary to center the blackout.

Mid America Motorworks, 17082 N. US Hwy 45, P.O. Box 1368, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800 • www.mamotorworks.com • mail@mamotorworks.com

Copyright Mid America Motorworks