



AMERICAN CAR CRAFT INSTRUCTIONS

Mobil 1 Oil Fill Cap Cover For C7 Corvette

Part# 053097



PARTS INCLUDED:

- 1- Chrome Cap Cover
- 1-Adhesive Promoter Pack

This new and unique oil cap cover is designed to set over the factory oil cap as a cosmetic cover only. This triple chrome-plated steel cap attaches easily and offers a clean custom look to your engine bay.

1. The first step for installation is to thoroughly scrub the top of the factory cap with alcohol to remove any surface contaminants, then swipe the top with the adhesive promoter provided.
2. You have been provided with 2" furry Velcro attachment cookies on the underside of the cap. Remove the foam insert and save it for later. Do not throw it out. Peel the Velcro top cookie off keeping the release liner in place. Now remove the plastic release liner and adhere the Velcro cookie firmly to the top of the factory cap molding it as needed until the furry Velcro is firmly seated and completely attached.



3. Reinsert the foam insert and then simply set the cap in place.

**If any questions occur during installation please email American Car Craft at
inquiries@americancarcraft.com**

Thank you and enjoy your purchase!

AMERICAN CAR CRAFT, 18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com