



# **AMERICAN CAR CRAFT INSTRUCTION**

---

## **CORVETTE C-5 PERFORATED ALTERNATOR COVER**

### **PART# 033051** patent pending



#### **ITEMS NEEDED:**

9/64 Drill Bit

#### **PARTS INCLUDED:**

2-Screws  
2-Plastic Washers  
2-Chrome Caps  
Stainless Alternator

1. Place your new cover into position.
2. Align the two holes in the cover with the main alternator bracket ridge. (This is a small area and must be matched up properly.)
3. Mark holes in cover to ridge in bracket using a fine point marker or scribe.
4. Using a 9/64 drill bit, drill marked holes only about 1/4" deep.
5. Place cover back over drilled areas and place screws (provided) through plastic washers then tighten. **BE CAREFUL NOT TO OVER TIGHTEN.** Push chrome caps (provided) onto screws until they snap into place.

**Thank you and enjoy your purchase!**

**If any questions occur during installation please contact**  
**AMERICAN CAR CRAFT**  
**18924 SAKERA ROAD-HUDSON FLORIDA 34667**  
**Phone # 727-861-1500 Fax # 727-861-1520**  
**[www.americancarcraft.com](http://www.americancarcraft.com)**