



AMERICAN CAR CRAFT INSTRUCTIONS

2005-2013 Corvette C6 - Crossed Flag 2 3/8" Raised Emblem Decals 2Pc Part #042123



PARTS INCLUDED:

2-Stainless Emblem Bezels

1. Clean the area around each emblem with household rubbing alcohol to remove any wax and dirt.
2. Place each bezel into position to familiarize yourself with each placement before removing the liner. It WILL BE necessary to HAND FORM the bezels to CONFORM to the shape of the car doing this will prevent any possibility of the bezel popping loose or lifting long term.
3. Once they are fitted properly peel the release liner from the back of each bezel and carefully set them nice and evenly around each emblem. Press firmly to set.

DO NOT GET WET FOR 24 HOURS.

Thank you and enjoy your purchase!

If any questions occur during installation, please contact

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500

Fax # 727-861-1520

www.americancarcraft.com