

www.ECPB.biz

ECPB Mid¹ C3-73 Corvette Electric Headlight Actuator Mounting Bracket

Installation Instruction

Read this second

Use the bracket stamped with "LEFT" on the driver side up and install it with the 7/16 x 1" long hex bolt and a lock washer to the open hole in your front bumper support bracket. Repeat the same for the passenger side use the "RIGHT" bracket.

It may be necessary to install the 7/16 bolt in the hole and run it in and out to clean the tread in the factory nut in the support bracket.

Align the electric actuator in between the mounting tabs and install the $\frac{1}{4}$ " hex bolt with the lock nut. Do not fasten tight, make sure it has free play and a little of movement.

