



ProTEKt Skid Plates Installation Instructions

This skid plate kit is secured using supplied fasteners.

All needed hardware is included. Drilling is required.

- 1. Position the skid plate on the underside of the front bumper cover and secure with low tack tape, ie., blue painter's tape (may refer to images on website for positioning if needed)**
 - 2. Lubricate bolts (recommended to avoid thread galling)**
 - 3. Drill the bumper cover using a 1/4" drill bit wherever there is a skid plate hole**
 - 4. Install the bolts, nuts and washers. Some disassembly may be required to access the inside of the bumper cover**
-

**DO NOT OVERTIGHTEN THE BOLTS THAT SECURE THE PROTEKT SKID PLATES TO THE BUMPER!
EXCESSIVE BOLT TORQUE CAN CAUSE FAILURE OF THE BUMPER COVER OR THE SKID
PLATES!**

For more info, go to www.proTEKtskidplates.com

Or email sales@protektskidplates.com

Thank you for your purchase!