



ProTEKt Skid Plates Installation Instructions

This skid plate kit is secured using a combination of factory and supplied fasteners. All needed hardware is included. Some drilling will be required.

- 1. Hold the included skid plates up to the bumper and remove any factory bolts or clips that would be covered by the plates**
 - 2. Secure the plates by replacing the factory fasteners**
 - 3. Lubricate included bolts (recommended to avoid thread galling)**
 - 4. Install the included bolts wherever there is a factory hole that corresponds to the skid plate holes (some disassembly may be required to gain access to the inside of the bumper cover)**
 - 5. Drill the bumper cover using a 1/4" drill bit to allow the remaining bolts to be installed**
 - 6. Tighten all fasteners securing the plates to the bumper cover**
-

**DO NOT OVERTIGHTEN THE BOLTS SECURING THE PROTEKT SKID PLATES TO THE SPLITTER!
EXCESSIVE BOLT TOURQUE CAN CAUSE FAILURE OF THE SPLITTER TABS, OR THE SKID
PLATES!**

For more info, go to www.proTEKtskidplates.com

Or email sales@protektskidplates.com

Thank you for your purchase!