



ProTEKt Skid Plates Installation Instructions

This skid plate kit is entirely secured using the factory splitter fasteners. The included hardware secures the skid plates to the included brackets. No drilling is required.

- 1. Remove the factory leading edge bolts that secure the splitter to the undertray**
 - 2. Secure the included brackets inside the winglets using the factory bolts**
 - 3. Place the ProTEKt Skid plates and secure them by loosely replacing the factory bolts**
 - 4. Use the included bolts to secure the skid plates to the brackets**
 - 5. Adjust the position of the plates until they line up perfectly with the outer edge of the splitter**
 - 6. Tighten the factory bolts, securing the ProTEKt Skid Plates to the splitter**
-

**DO NOT OVERTIGHTEN THE BOLTS SECURING THE PROTEKT SKID PLATES TO THE SPLITTER!
EXCESSIVE BOLT TOURQUE CAN CAUSE FAILURE OF THE SPLITTER TABS, OR THE SKID
PLATES!**

For more info, go to www.proTEKtskidplates.com

Or email sales@protektskidplates.com

Thank you for your purchase!