

C7 ENGINE BAY LED KIT



This image shows the 3 way splitter installed between the control box and the engine bay strips. The empty connector gets connected to the coil cover kit. Be sure to align the Arrows on the connectors when plugging them in. Test the strips before mounting them.

This shows how to mount the drivers side led strip directly under the lip of the fender. Start the strip near the cover (red arrow) so you can hid the wire behind it. Prep the area with alcohol then Cut off the very top of the adhesion promotor packet and squeeze the fluid back into the packet as you remove it. Prep both fenders and let it dry. Fold over the top and seal it to conserve the fluid. Peel the backing and mount the strip. You can hide the wire going over to the passenger side under the cowl weather strip or tape it under the cowl itself.



Mount the strip on the passenger side in the same fashion as the drivers side. You can start the strip near the black cover (red arrow) but the end wont line up with the strip on the other side. Alternatively you can mount it as shown and secure the wire with gorilla tape. Route the wire behind the black cover. The wire for the passenger side is extra long so you will have to hide the extra down inside the fender.



Finally hide all wiring and secure it. Go back and press the led strips in place a final time.