

# 1963-1982 Corvette Body Lift Kit

Product # ZM-293

## Installation Instructions

### Prepare Body Lift Kit

Remove all components that attach to the body and chassis, such as: Steering column, gas and brake lines, rear exhaust tips, mufflers, bumpers, shifter, clutch linkage, oil pressure lines, seat belt straps, battery cables, gas tank wires, body mount bolts, rocker moldings, and side exhaust.

### Lift Body

1. Center lift over shifter hole.
2. Attach one pair of strap hooks just forward of the rear door gap.
3. Attach the other pair of straps forward of door on front most portion of metal substructure.  
The metal substructure does not run the entire length of the rocker panel. Look behind the fiberglass to be certain the hook is on the metal, not just attached to the fiberglass.
4. Break body loose from frame with a long pry bar. (Rust will prevent the easy removal from the body mounts.) Do not attempt to lift until body is loose. If any resistance is met, STOP and locate the problem.
5. Lift.
6. Once the body is lifted, never get under the suspended body.
7. After raising the body, remove the chassis and lower immediately.
8. Reverse procedure when reassembling vehicle.

Note: Make sure chain fall is securely fastened to overheard structure and that it is strong enough to handle the body weight (as much as 1000 lbs.). Also make sure chain fall can handle appropriate weight.

**[www.zip-corvette.com](http://www.zip-corvette.com)  
1-800-962-9632**



Zip: Corvettes are all we do.